



## The Ascom Myco 3 smartphone for DECT and Wi-Fi networks



*The Ascom Myco 3 smartphone operates on DECT and Wi-Fi networks to offer the best of both worlds: the renowned reliability and telephony quality of DECT, and the smartphone apps and services enabled by Wi-Fi.*

### **DECT and Wi-Fi benefits from one rugged device**

The Ascom Myco 3 lets you benefit from the best of DECT and Wi-Fi networks. DECT delivers unsurpassed network availability, and interference-free communications and voice quality thanks to dedicated frequency bands. Wi-Fi lets Ascom Myco 3 users access and use a rich ecosystem of enterprise-grade apps and services.

### **From fragmented data to fluent workflows**

The Ascom Myco 3 together with supported apps unlock and connect siloed information; helping your organization to:

- Share information across dispersed teams to help coordinate time-sensitive activities
- Turn multi-step and multi-location activities into coordinated workflows and communication

### **Optimized interaction and sound quality**

The Ascom Myco 3 features a high-definition 5" display for optimal interfacing and management of alerts, messages and visual data. Sound quality is exceptional, thanks to wide-band audio and noise and echo cancellation—critical for workplaces with high ambient noise levels.

### **Continuous power for continuous performance**

The Ascom Myco 3 features a powerful octa-core processor to support smooth multitasking. Its true hot-swappable battery helps maximize uptime and productivity—no need to power down or exit apps when changing batteries.

### **Automatic personal alarms**

'Man-down' and 'no-movement' alarms are automatically sent to designated recipients should the device experience a sudden fall or not move beyond a pre-set time.



Integrated barcode scanner for fast, easy ID verification when administering medications.

# Ascom Myco 3

## –Mobility, safety, productivity

### ■ Full high-definition 5" touchscreen

Easy user interface with alerts, photos, messages, scores and other critical information. Large screen supports efficient multitasking.

### ■ Rugged construction

Features an aluminum chassis and Corning® Gorilla® Glass 3. Dust- and water-resistant to IP67 standard. Tolerates disinfectants. Hot-swap battery helps ensure constant operation throughout long shifts.

### ■ Tools for safety and efficiency

Infrared (IR) location function with room-level accuracy supports rapid emergency responses. Integrated barcode scanner for fast and secure ID verification, smooth inventory management and data collection. NFC function supports two-way communication.

### ■ Designed for efficiency and comfort

Integrated barcode scanner. Top-positioned LED beacon means color-coded alert notifications can be seen at a glance. Sturdy carrying clip comfortably secures the Ascom Myco 3 to clothing.

### ■ Customizable and flexible

Built on Android Enterprise. Enables user-interface customization for preferred information, applications and workflow management.

#### ASCOM MYCO 3 TECHNICAL SPECIFICATIONS

<b>Platform</b>	OS CPU	Android 9 Pie 2.3/1.8 GHz Octa-core
<b>Body</b>	Dimensions	150 x 76 x 14/16 mm 5.90" x 2.99" x 0.55/0.63"
	Weight Build	239 g / 8.43 oz. Aluminum chassis
<b>Battery</b>	Type	Replaceable 2935 mAh
<b>Display</b>	Type Size	Full HD 5"
	Resolution Multi touch Protection	1920 x 1080 (FHD) Deca point capacitive touch Corning® Gorilla® Glass 3
<b>Network</b>	Technologies	DECT / Wi-Fi
<b>Memory</b>	Internal	4 GB RAM, 32 GB Flash
<b>Scanner</b>	Barcode	1D / 2D barcodes
<b>Sensors</b>		Three-axes accelerometer Three-axes gyroscope Proximity sensor Light sensor Ascom IR location
<b>Indication</b>		Multi-color top LED
<b>Camera</b>	Front-facing	5 MP
	Rear-facing	13 MP, autofocus, flash 4160 x 3120 pixels
<b>Communications</b>	DECT	Frequency: EU: 1880-1900 MHz, BR: 1910-1920MHz, LA: 1910-1930MHz, US: 1920-1930MHz, Other: 1900-1920MHz Modulation: GFSK Security: EN300 444 feature N35, as specified by DECT forum
	WLAN	IEEE 802.11 a/b/g/n/ac IEEE 802.11 k/r/v
	Bluetooth GNSS	4.1 A-GPS; GLONASS
	NFC	NFC Forum Type 1-5
<b>Ports</b>	USB	Micro USB
	AUDIO	3.5 mm audio jack
<b>Buttons</b>		3 programmable multi-function buttons; 1 on top, 2 on sides
<b>IP rating</b>	IP67	Dust and water resistant
<b>Accessories</b>		See <a href="http://ascom.com">ascom.com</a>

Contact your nearest Ascom office for further technical data and specifications. For contact details, go to: [ascom.com](http://ascom.com)

Multiple products from Ascom and third parties support the functions and features described. All Ascom solutions may not be available in specific countries.

Google and Android are trademarks of Google LLC.  
Corning and Gorilla are registered trademarks of Corning Incorporated.

**Ascom Holding AG**  
Zugerstrasse 32  
CH-6340 Baar  
Switzerland  
[info@ascom.com](mailto:info@ascom.com)  
Phone: +41 41 544 78 00  
[ascom.com](http://ascom.com)

**ascom**