

[PRODUCT SHEET]

Product:	Ascom 9d24 Talker
	Robust DECT telephone
	GAP/CAP compatible
	Tested on Ascom IP-DECT, MX-One and BusinessPhone
	Messaging and Alarm functionalities available with licences



ASCOM 9d24 TALKER

COMMUNICATE WHEREVER YOU ARE

Equipped with an Ascom 9d24 Talker, you can talk anywhere. This slim yet robust handset is designed both for truly demanding environments and a smooth day at the office. Perfect for professionals on the move, the Talker reduces waiting time, speeds up service and improves quality. The Talker is part of the Ascom 9d system and is easily adaptable to existing Ascom systems.

Built to take it

Featuring a scratchproof keypad, Ascom 9d24 Talker is also made to withstand dirt, water and crash landings on the floor – though you won't have to worry too much about the latter thanks to a secure slip function.

A multi-purpose handset

The Talker is designed to organise and simplify your working day. It's also extremely durable, easy to handle, while also featuring a big, bright backlit display for excellent readability. What's more, the Talker offers loudspeaker for hands-free operation and a vibrator for silent calls.

Always in touch

The 9d24 Talker is the ideal choice for workplaces where personnel are constantly on the move and need to get in touch with just the touch of a button: factories, hotels and hospitals, for example.

Keep it personal

The Talker houses a SIM card for identity and personal settings, including a local phonebook. The central phonebook features an impressive name length of up to 120 characters, a maximum number length of up to 60 digits as well as an unlimited number of entries. In addition, the Talker boasts as many as 10 personalised settings.

[PRODUCT SHEET: ASCOM 9d24 TALKER]

Features	
Call list/local phonebook	Convenient access to the 20 latest calls and sufficient memory for 100 entries in the local phonebook.
Central directory	Direct access to the company phonebook is available separately.
Dust, moisture and shock proof	The handset is both dust and water-resistant in accordance with IP64 and designed to withstand shock in accordance with IEC 68-2-32 (it was dropped twelve times from 1 meter onto solid concrete).
Hands-free operation	A separate loudspeaker together with signal processing allows hands-free operation and use of the handset for conference calls. When placed in the charger, the handset functions perfectly as a normal desktop phone.
Illuminated keys	The alphanumeric keypad is backlit to facilitate use of the handset in bad light conditions. What's more, bright backlighting of display and keypad ensures readability.
Keys for intuitive operation	A central navigation key allows convenient orientation of the menus. Personalised soft keys and hot keys give easy access to the most commonly used functions.
Large graphic display	A bright illuminated display showing call list, phonebook and settings.
SIM card identification	Each user has a SIM-card, storing the handset ID and all personal settings, including profiles and soft key functions. It's easily transferred from one handset to another when the time comes.
Theft protection	It is possible to pre-set the phone to work in a specified system – and nowhere else.
Vibrator for silent calls	A built-in vibrator makes silent calls "heard".
	All messaging features are system dependent and require additional equipment.

Accessories/options

- Medic version
- Headsets with microphone
on cable or boom
- Headset with hearing protection
- Security string
- Clips
- Desktop charger
- Charging rack
- Leather case



Manual or automatic?

Other features and functions include manual or automatic keypad lock as well as time and date indication. Naturally, ring signals (5 to choose from) can be easily muted – a flashing LED and vibrator keeps you on call. The Talker also features a separate loudspeaker and a water resistant (IP64 classified) headset connector. Furthermore, a generous number of volume steps allow you to quickly find the right level for you.

Long-lasting with a big capacity

Complemented by a battery pack adapter, Talker's Lithium Ion battery is longer lasting than ever before and complemented by a battery pack adapter. In fact, battery charging continues even during a call once the handset has been placed in a charger.

The Talker provides a comprehensive call list storage capacity: 20 received, made, and missed calls with time stamp.

Talker is also upgradeable with licence to both the 9d24 MkII Messenger and 9d24 MkII Protector.

Ascom

Wireless Solutions

P.O. Box 8783 SE-402 76 Göteborg, Sweden
T +46 31 55 93 00 | F +46 31 55 20 31
www.ascom.com