



## teleCARE M Patient handsets.

Create better care with our patient handsets. They are designed to help nurses in their daily work and for patients to feel safe. With buttons clearly marked with colours and symbols, life gets easier for everyone.

The teleCARE M patient handsets combine functionality and good design as well as offer the patient a comprehensive set of services. Four specifically developed handsets ranging from a single call button to a multi-purpose handset with speech, radio and TV control, bed-light control, headset connection, etc., can be combined in any teleCARE M system.

### **Easy-to-use design**

All handsets are lightweight, very compact and durable. In addition, they are waterproof and can be "dip-sterilised". Each button is clearly marked with colours and symbols to show

their functionality. The call button on each handset is large and permanently backlit to help the patient locate it in the dark. The LED lights up when the button is pushed to reassure the patient that the call is registered.

### **Durable quality**

The Safe Release plug connects the handset to the switch module and is automatically released if excessive strain is applied to the handset cable. This significantly reduces the number of damaged plugs and broken cables, saves repair costs and increases system reliability. With the choice of two colours, the teleCARE M patient handsets cover all nurse call requirements for hospitals and care homes.



## Features

### Safe Release plug

Releases from the socket which saves repairs.

### Clearly marked buttons

Easy to identify and use.

### Permanently backlit call button

For easy location, day or night.

### Reassurance LED

Indicates that the call is registered.

### Waterproof and "Dip-sterilisable"

For easy cleaning and care.

### Full flexibility

Supports all combinations on bed level.

### Ergonomic design

Durable and comfortable use.

### Accessories

Handset holders

Linen clip



Safe Release plug	x	x	x	x
Waterproof & Dip-sterilisable	x	x	x	x
Call Button Backlight	x	x	x	x
Speech				x
Light 1		x	x	x
Light 2		x	x	
Radio/Music			x	x
Music Headset Connection			x	x
TV Control			x	x
IP-classification	IP67	IP67	IPx7	IPx7
Weight (gr)	85	85	155	220
Size (mm)	50x90	50x90	55x135	55x182
White	x	x		
Light grey	x	x	x	x
RJ22 Plug	x			