

Ascom 914T

The robust pocket receiver with a two-line display

The Ascom 914T is small enough to fit comfortably in a pocket. It is especially developed to withstand impact and hard use. smart functions make it easy to operate. this is the perfect message receiver for hospitals and industries.

Fast facts

- Multilingual display
- The 914T is dust and waterproof
- Stores up to 10 messages or 480 characters
- Fits in a shirt pocket

We devoted special thought to the needs of hospital staff and industry workers when developing the 914T message receiver. Resilience is essential in these demanding environments, where equipment is subjected to heavy punishment on a daily basis. The 914T is able to withstand impact and hard use. It is both dust and water-proof in accordance with IP64 classification.

Resilient and reliable messenger

A smart, simple and slim design makes it really easy to use. there is only one operating button, which serves all functions. Long messages are automatically scrolled, showing two lines at a time, twelve characters per line, until the complete message has been displayed. It is possible to set the receiver to alert with seven different types of signals for quick identification of messages. several other useful functions will ensure that your 914T serves as your reliable partner for many, many working hours.



All pagers can be powered by disposable or specially designed rechargeable NiMH batteries. Both pagers and batteries are made of materials non-hazardous to the environment. Ascom provides you with a smarter choice. The 914T takes a logical part in the system 900 product range.

Intrinsically safe

The 914T is also available in an explosive proof version which is certified to be used for a top degree of protection in hazardous areas, such as petroleum industries and chemical industries. For its products, Ascom follows the AteX directive for Europe, CSA certification for North America and the IECEx scheme for rest of the world.

ascom

To learn more about TrakCare go to <https://www.intersystems.com/products/trakcare>

Features

Durable design	The 914T is dust and waterproof in accordance with IP64 classification, it is designed to withstand shock
Large display	24-character display with auto scrollfunction
Seven alert characteristics	Message priority identified by the signal
One button for all functions	Smart programming makes it easy to operate with just one button
Compact and lightweight	Fits in a shirt pocket
Auto scroll function	Messages of up to 120 characters can be received and displayed automatically
Message storage	Stores up to 10 messages or 480 characters
Record of date and time	Easy to check when message was received
Out of range indicator	Indicates when you have left the area covered by the messaging system
Group pagings	One message is forwarded to several receivers
Different signals	Choose both tone and light alert signals
Multilingual display	Cyrillic, Greek, Hebrew and Arabic available in first software release
Basic data	Size: 86 x 51 x 19 mm. Weight: 84 g including battery.
Options	Vibrator, intrinsically safe version, EEx ib IIC T4, (only steel grey colour)
Colour	Steel Grey, Ice Blue

Accessories

Charging rack	Charging 8 units. Small area needed (36 x 13 x 7 cm). Absent handling as option.
Belt clip, clic-on type	A convenient way to carry your 914T – always at hand. Material TPE.
Safety string	Length 80 cm or 35 cm

Functions

Different beep codes	7
Characters per message	120
Messages stored	10
Characters in memory	480
Group paging numbers	5
Absence indication	Yes
Time stamp	Yes
Time display	Yes
Out of range indication	Yes
Silent mode	Yes

ascom

To learn more about TrakCare go to <https://www.intersystems.com/products/trakcare>