


[ FUNCTIONALITY SHEET ]

Function: Easy replacement

Available in Ascom d41/d62 and d81

Minimises work for the administrator



## EASY REPLACEMENT – A DO-IT-YOURSELF ADMINISTRATION TOOL

If a handset (Ascom d41/d62 or d81) needs to be replaced due to for example a broken display or mechanical disorder it can be done immediately by the end-user. No need to contact your IT administrator.

The following settings are replaced during

**Easy Replacement:**

- DECT registration
- User parameters
- Contacts

The following settings are not replaced:

- Call list
- Messages
- Bluetooth pairing list
- Licences

Both the old handset and the new handset must be of the same device type (d41/d62 or d81). The same extension number is assigned to the new handset.

The Easy replacement procedure is done via the handset display and does not involve a PDM. Instead an Advanced Desktop Charger or a Rack Charger is used. It takes not more than 5 minutes, and saves a lot of downtime for the user.

### Can you read? Then you can also replace your malfunctioning handset with a new one!

Follow the instructions on the display in a few steps.

1. The 'new' handset shall be switched off. Press **and** hold the Off-hook key at the same time as you put the handset in the charger. Start the procedure by pressing YES
2. Insert the 'old' phone in charger
3. Do not remove the phone while saving settings
4. Insert new phone
5. Wait until 'restoring settings' is finalised
6. The phone is successfully replaced
7. Remove the phone to restart

For more information see separate instructions:

–EASY REPLACEMENT PROCEDURE

**Ascom Wireless Solutions**

P.O. Box 8783 SE-402 76 Göteborg, Sweden  
 T +46 31 55 93 00 | F +46 31 55 20 31  
 www.ascom.com